

Notification of STEMCO Gaff Part Number Inactivations

To: All Distributors of STEMCO Suspension Products

STEMCO is inactivating the following GAFF part numbers effective immediately. Please update your system to remove these part numbers. Part number reactivation may occur based on customer demand.

Part Number	Description	Part Number	Description	Part Number	Description	Part Number	Description
10000	TORQUE ROD BUSHING	11505	TORQUE ROD BUSHING	12054	TORQUE ROD	13656	CENTER BUSHING
10001	FIFTH WHEEL MOUNT	11506	TORQUE ROD BUSHING	12310	HOOD GUIDE	13659	TORQUE ROD BUSHING
10010	CAB MOUNT	11509	TORQUE ROD BUSHING	12317	STABILIZER BAR BUSHING	13662	BEAM BUSHING KIT
10012	RADIATOR MOUNT	11510	TORQUE ROD BUSHING	12318	TORQUE ROD BUSHING	13671	SUSPENSION BUSHING
10013	RADIATOR MOUNT	11513	TORQUE ROD BUSHING	12329	SPRING BUSHING	13680	TORQUE ROD
10014	RADIATOR MOUNT	11514	TORQUE ROD BUSHING	12334	END PLUG	13681	TORQUE ROD END
10016	RADIATOR MOUNT	11518	TRUNNION BUSHING	12375	SHACKLE	13682	TORQUE ROD END
10017	MOTOR MOUNT	11534	MOTOR MOUNT	12379	TORQUE ROD	13684	TORQUE ROD BUSHING
10021	MOTOR MOUNT	11542	FUEL PEDAL MOUNT	13009	TRUNNION BUSHING	13689	TORQUE ROD END ASSY
10022	MOTOR MOUNT	11546	HOOD GUIDE	13010	SPRING PAD	13692	TORQUE ROD END ASSY
10025	HOOD HINGE BUSHING	11552	CAB MOUNT	13503	BEAM BUSHING KIT	13693	TORQUE ROD END ASSY
10027	HOOD PACKING PAD	11556	TORQUE ROD BUSHING	13504	BEAM BUSHING KIT	13696	TORQUE ROD END ASSY
10032	MOTOR MOUNT	11560	TORQUE ROD BUSHING	13508	BEAM BUSHING KIT	13698	TORQUE ROD END ASSY
10074	SPRING BUSHING	11561	TORQUE ROD BUSHING	13511	SPRING BUSHING	13700	TORQUE ROD END ASSY
10507	HOOD PIN	11572	FIFTH WHEEL BUSHING	13516	TORQUE ROD BUSHING	13701	TORQUE ROD END ASSY
10510	HOOD LATCH	11575	FIFTH WHEEL BUSHING	13517	TORQUE ROD BUSHING	13702	TORQUE ROD END ASSY
11001	TORQUE ROD BUSHING	11715	TORQUE ROD BUSHING	13526	EQUALIZER BUSHING	13707	TORQUE ROD END
11003	TORQUE ROD BUSHING	11716	TORQUE ROD BUSHING	13532	TORQUE ROD BUSHING	13708	TORQUE ROD END
11006	TORQUE ROD BUSHING	11728	FUEL TANK GASKET	13539	CENTER BUSHING	13725	SPRING MOUNT KIT
11012	CAB MOUNT	11731	TOOL R & I	13541	INNER BUSHING SLEEVE	14000	EQUALIZER BUSHING
11013	MOTOR MOUNT	11732	TOOL R & I	13549	BEAM END ADAPTER	14001	EQUALIZER BUSHING
11015	MOTOR MOUNT	11735	TORQUE ROD BUSHING	13558	CENTER BUSHING KIT	14003	TORQUE ROD BUSHING
11023	CAB MOUNT	11741	TORQUE ROD BUSHING	13560	BEAM END BUSHING	14004	TORQUE ROD BUSHING
11056	HOOD HINGE BUSHING	11754	TORQUE ROD	13562	BEAM END BUSHING KIT	14007	TORQUE ROD BUSHING
11062	HOOD HINGE BUSHING	11775	SPRING BUSHING	13572	TOOL INSTALL	14011	TORQUE ROD BUSHING
11063	SPRING PIN BUSHING	12001	RADIATOR MOUNT	13574	BEAM END BUSHING KIT	14012	EQUALIZER BUSHING
11079	TOOL INSTALL	12003	MOTOR MOUNT	13585	TOOL R & I	14014	TORQUE ROD BUSHING
11095	MOTOR MOUNT	12029	TRUNNION BUSHING	13586	BEAM END BUSHING KIT	14015	TORQUE ROD BUSHING
11110	CAB MOUNT KIT	12037	TRUNNION BUSHING KIT	13590	TORQUE ROD	14016	TORQUE ROD BUSHING
11115	TRANSMISSION BUSHING	12038	TRUNNION BUSHING KIT	13597	TORQUE ROD	14017	TORQUE ROD BUSHING
11118	CLUTCH BAR BUSHING	12041	SPRING PIN BUSHING	13610	BEAM END ADAPTER KIT	14018	TORQUE ROD BUSHING
11503	TORQUE ROD BUSHING	12043	SPRING BUSHING	13629	TORQUE ROD	14021	TRUNNION BUSHING

Part Number	Description	Part Number	Description	Part Number	Description	Part Number	Description
14022	EQUALIZER BUSHING	16506	MOTOR MOUNT	17516	PUMP VALVE COVER	18107	CARRIER BEARING BUSHING
14030	TORQUE ROD BUSHING	16507	MOTOR MOUNT	17518	COUPLING	18118	BEAM END BUSHING
14031	TORQUE ROD BUSHING	16509	MOTOR MOUNT	17519	COUPLING	18222	CAB MOUNT
14032	TORQUE ROD BUSHING	16510	MOTOR MOUNT	17520	COUPLING	18229	SPRING SPACER
14071	TORQUE ROD BUSHING	17000	SPRING BUSHING	17529	CAMSHAFT BUSHING	18230	SPRING SPACER
14072	EQUALIZER BUSHING	17001	SPRING BUSHING	17530	COUPLING	18232	MOTOR MOUNT
14500	TRUNNION BUSHING	17002	SPRING BUSHING	17531	COUPLING	18233	TORQUE ROD BUSHING
14501	TRUNNION BUSHING	17003	SPRING BUSHING	17538	CAMSHAFT BUSHING	18240	SHOCK ABSORBER SLEEVE
14503	TRUNNION BUSHING	17004	SPRING BUSHING	17539	CAMSHAFT BUSHING	18259	TORQUE ROD BUSHING
14504	BEAM END BUSHING	17005	SPRING BUSHING	17574	CAMSHAFT BUSHING	18290	OIL PLUG
14509	AXLE PAD	17006	SPRING BUSHING	17668	CAMSHAFT BUSHING	18310	FUEL TANK CAP GASKET
14524	TRUNNION BUSHING	17019	SPRING BUSHING	17677	COUPLING	18316	SHOCK ABSORBER BUMPER
14526	CENTER BUSHING	17030	SPRING BUSHING	17678	CAMSHAFT BUSHING	18317	SPRING BUSHING
14529	CENTER BUSHING	17031	SPRING BUSHING	17682	CAMSHAFT BUSHING	18318	SPRING BUSHING
14530	BEAM END BUSHING	17032	SPRING BUSHING	18000	CARRIER BEARING BUSHING	18320	FUEL TANK CAP GASKET
15005	EQUALIZER BUSHING	17033	SPRING BUSHING	18006	FLAG	18333	HINGE BUSHING KIT
15006	EQUALIZER BUSHING	17034	TORQUE ROD BUSHING	18008	FLAG	18351	FIFTH WHEEL MOUNT
15009	TORQUE ROD BUSHING	17035	SPRING BUSHING	18014	VIBRATION MOUNT	18352	STABILIZER BAR BUSHING
15017	EQUALIZER BUSHING	17036	SPRING BUSHING	18030	RADIATOR MOUNT	18433	MOTOR MOUNT
15018	EQUALIZER BUSHING	17037	SPRING BUSHING	18034	SHOCK ABSORBER BUSHING	18435	TORQUE ROD BUSHING
15054	EQUALIZER BUSHING	17039	SPRING BUSHING	18045	FUEL TANK PLUG	18437	LOAD CUSHION
15059	EQUALIZER BOLT	17250	STABILIZER BAR BUSHING	18046	FUEL TANK PLUG	18439	CAMSHAFT BUSHING
15062	TORQUE ROD BUSHING KIT	17251	STABILIZER BAR BUSHING	18048	SHOCK ABSORBER BUSHING	18483	SHOCK ABSORBER BUSHING
16000	STABILIZER BAR BUSHING	17257	MOTOR MOUNT	18049	LOAD BUSHING	18484	LOAD CUSHION
16001	SPRING BUSHING	17272	STABILIZER BAR BUSHING	18051	TOOL INSTALL	18526	BUSHING
16002	SPRING BUSHING	17273	STABILIZER BAR BUSHING	18053	SEAT BUSHING	18529	TRAILER & DOCK BUMPER
16003	SPRING BUSHING	17275	SPRING BUSHING	18058	FLAG	18538	TORQUE ROD MOUNT
16004	SPRING PAD	17276	SPRING BUSHING	18065	SHOCK ABSORBER BUSHING	18552	TOOL FOR R & I
16005	SPRING PAD	17279	STABILIZER BAR BUSHING	18067	MOTOR MOUNT	18559	TRAILER & DOCK BUMPER
16006	LOWER SHOCK	17283	EXHAUST BUSHING	18069	VALVE SEAL	18568	TORQUE ROD BUSHING
16007	OVERLOAD CUSHION	17290	EXHAUST BUSHING	18070	MOTOR MOUNT	18572	SHOCK ABSORBER BUSHING
16008	LOWER SHOCK	17291	EXHAUST BUSHING	18072	FLAG	18581	CURTAIN ROLLER
16032	SPRING BUSHING	17292	EXHAUST BUSHING	18076	TRAILER & DOCK BUMPER	18599	SHACKLE
16033	SPRING BUSHING	17500	CAMSHAFT BUSHING	18079	CAB MOUNT	18686	HINGE BUSHING KIT
16034	SPRING BUSHING	17501	CAMSHAFT BUSHING	18080	TORQUE ROD BUSHING	18689	TORQUE ROD BUSHING
16501	SPRING BUSHING	17502	CAMSHAFT BUSHING	18081	CAB MOUNT	18692	TORQUE ROD BUSHING
16502	SPRING BUSHING	17503	CAMSHAFT BUSHING	18084	TORQUE ROD BUSHING	18693	TORQUE ROD BUSHING
16503	SHOCK ABSORBER BUSHING	17504	CAMSHAFT BUSHING	18086	BUSHING	18696	SHOCK ABSORBER BUSHING
16504	SHOCK ABSORBER BUSHING	17505	CAMSHAFT BUSHING	18096	BUSHING	18697	SHOCK ABSORBER BUSHING
16505	SHOCK ABSORBER BUSHING	17509	COUPLING	18103	CAB MOUNT	18698	SUSPENSION MOUNT

Part Number	Description	Part Number	Description	Part Number	Description	Part Number	Description
18699	SUSPENSION MOUNT	30505	TORQUE ROD BUSHING	31062	SHOCK ABSORBER BUSHING	31548	STABILIZER BAR BUSHING
18702	SUSPENSION BUSHING	30506	TORQUE ROD BUSHING	31063	SHOCK ABSORBER BUSHING	31550	RADIATOR MOUNT
18705	SUSPENSION BUSHING	30508	LOAD PAD	31064	SHOCK ABSORBER BUSHING	31551	BUSHING KIT
18730	SPRING SPACER	30509	MOTOR MOUNT	31065	SHOCK ABSORBER BUSHING	31552	RADIATOR MOUNT
18733	PIVOT BUSHING	30510	MOTOR MOUNT	31068	TORQUE ROD BUSHING	31553	STABILIZER BAR BUSHING
18745	THRUST WASHER	30511	COMPRESSOR MOUNT	31069	TORQUE ROD BUSHING	31554	SPRING BUSHING
18746	TORQUE ROD BUSHING	30513	RADIATOR MOUNT	31070	STABILIZER BAR BUSHING	31556	BEARING WASHER
18747	TORQUE ROD BUSHING	30515	SUSPENSION MOUNT	31071	END PLUG	31560	ALTERNATOR BUSHING
18748	THRUST WASHER	30520	RADIATOR MOUNT	31072	STABILIZER BAR BUSHING	31561	SHIFTER LINKAGE BUSHING
18750	PIVOT BUSHING	30522	SHOCK ABSORBER BUSHING	31074	SPRING BUSHING	31562	CAB MOUNT
18753	SPRING BUSHING	30539	SHOCK ABSORBER BUSHING	31080	SPRING BUSHING	31564	STABILIZER BAR BUSHING
18757	BUSHING	30557	SHOCK ABSORBER BUSHING	31082	V-STAY REPAIR KIT	31565	STABILIZER BAR BUSHING
18758	EXHAUST BUSHING	31000	TORQUE ROD BUSHING	31086	MOTOR MOUNT	31566	STABILIZER BAR BUSHING
18760	CAB MOUNT	31001	STABILIZER BAR BUSHING	31087	TORQUE ROD BUSHING	31567	STABILIZER BAR BUSHING
18762	BUSHING	31002	SHOCK ABSORBER BUSHING	31088	TORQUE ROD BUSHING	31569	SHIFTER LINKAGE KIT
18788	SHOCK ABSORBER BUMPER	31004	SHOCK ABSORBER BUSHING	31089	V-STAY BUSHING	31570	STABILIZER BAR BUSHING
18814	STABILIZER BAR BUSHING	31005	RADIATOR MOUNT	31090	V-STAY BUSHING	31571	SHIFTER LINKAGE BUSHING
18820	STABILIZER BAR BUSHING	31006	RADIATOR MOUNT	31091	TOOL R & I	31578	SHOCK ABSORBER BUSHING
18822	SLIDE ROLLER	31007	RADIATOR MOUNT	31093	TORQUE ROD BUSHING	31579	TORQUE ROD BUSHING
18834	TOOL MOUNT	31012	HOOD MOUNT	31095	TORQUE ROD ASSY	31580	STABILIZER BAR BUSHING
18835	TOOL MOUNT	31014	ALTERNATOR BUSHING	31096	TORQUE ROD BUSHING	31581	SHOCK ABSORBER BUSHING
18851	HINGE BUSHING	31016	TORQUE ROD BUSHING	31097	TORQUE ROD	31582	SPRING BUSHING
18857	SPRING BUSHING	31017	SHOCK ABSORBER BUSHING	31098	V-STAY BUSHING	31583	STABILIZER BAR BUSHING
18865	TORQUE ROD BUSHING	31018	TORQUE ROD BUSHING	31502	SHOCK ABSORBER BUSHING	31588	WEAR SHIM
18866	TORQUE ROD BUSHING	31019	CAB MOUNT	31505	STABILIZER BAR BUSHING	31594	STABILIZER BAR BUSHING
18930	TORQUE ROD BUSHING	31021	MOTOR MOUNT	31507	STABILIZER BAR BUSHING	31595	COMPRESSOR MOUNT
18936	TOOL INSTALL	31026	FAN HOOD MOUNT	31508	TORQUE ROD BUSHING	31598	WEAR PAD
18943	MOTOR MOUNT	31031	COMPRESSOR MOUNT	31509	SPRING BUSHING	31600	MOTOR MOUNT
18956	BEAM END BUSHING	31037	STABILIZER BAR BUSHING	31512	STABILIZER BAR BUSHING	31609	STABILIZER BAR BUSHING
18984	TORQUE ROD BUSHING	31040	MOTOR MOUNT	31514	STABILIZER BAR BUSHING	32000	STABILIZER BAR BUSHING
18991	CAMSHAFT BUSHING	31049	WEAR PAD	31515	COUPLING	32001	SPRING BUSHING
18992	CAMSHAFT BUSHING	31051	STABILIZER BAR BUSHING	31520	SHIFTER WASHER	32002	SPRING BUSHING
19001	SPRING BUSHING KIT	31052	SPRING BUSHING	31521	MOTOR MOUNT	32003	OVERLOAD PAD
19003	LOAD SPRING	31053	STABILIZER BAR BUSHING	31524	EXHAUST MOUNT	32005	STABILIZER BAR BUSHING
19004	CENTER BUSHING	31054	SHOCK ABSORBER BUSHING	31528	TORQUE ROD BUSHING	32006	STABILIZER BAR BUSHING
19005	BEAM END BUSHING	31055	SHOCK ABSORBER BUSHING	31529	MOTOR MOUNT	32008	TORQUE ROD BUSHING
19008	BEAM END BUSHING	31056	STABILIZER BAR BUSHING	31537	STABILIZER BAR BUSHING	32010	MOTOR MOUNT
20321	PISTON CUP	31057	STABILIZER BAR BUSHING	31539	FAN HOOD MOUNT	32013	EXHAUST MOUNT
30500	MOTOR MOUNT	31059	MOUNT	31546	STABILIZER BAR BUSHING	32016	SHOCK ABSORBER BUSHING
30503	MOTOR MOUNT	31060	LOAD PAD	31547	STABILIZER BAR BUSHING	32020	TORQUE ROD BUSHING



STEMCO®

A Higher Standard of Performance.™

an EnPro Industries company

Making the Roadways Safer®

STEMCO - USA 300 Industrial Drive – Longview, TX 75602 • (903) 758-9981 • 1-800-527-8492 • FAX: 1-800-874-4297

STEMCO - Canada 5775 McLaughlin Road – Mississauga, ON L5R 3P7 • (905) 206-9700 • 877-232-9111 • FAX: 877-244-4555

STEMCO is a registered trademark of STEMCO Products, Inc. © 2020 STEMCO Products, Inc. • Printed in the USA

www.stemco.com



Part Number	Description	Part Number	Description	Part Number	Description	Part Number	Description
32025	SHIFTER LINKAGE BUSHING	32044	SPRING BUSHING	33506	TORQUE ROD BUSHING	35001	STABILIZER BAR BUSHING
32027	SHIFTER LINKAGE BUSHING	32046	STABILIZER BAR BUSHING	33507	TORQUE ROD BUSHING	35002	TORQUE ROD BUSHING
32028	STABILIZER BAR BUSHING	32047	STABILIZER BAR BUSHING	34505	MOTOR MOUNT	35003	MOTOR MOUNT
32032	TORQUE ROD BUSHING	32048	TORQUE ROD BUSHING	34506	MOTOR MOUNT	35004	MOTOR MOUNT
32033	STABILIZER BAR BUSHING	32049	TORQUE ROD BUSHING	34512	TORQUE ROD BUSHING	35005	LOAD PAD
32035	TORQUE ROD BUSHING	32050	STABILIZER BAR BUSHING	34517	SPRING BUSHING	35006	STABILIZER BAR BUSHING
32037	STABILIZER BAR BUSHING	32053	STABILIZER BAR BUSHING	34519	SPRING BUSHING KIT	35007	TORQUE ROD BUSHING
32038	MOTOR MOUNT	32502	SPRING BUSHING	34523	SPRING BUSHING	35008	TORQUE ROD BUSHING
32039	MOTOR MOUNT	33501	STABILIZER BAR BUSHING	34532	CAB MOUNT BUSHING	35009	STABILIZER BAR BUSHING
32040	CARRIER BEARING BUSHING	33502	TORQUE ROD BUSHING	34536	HOOD GUIDE	50022	TRAILER & DOCK BUMPER
32041	BUSHING SHAFT	33503	TORQUE ROD BUSHING	34537	SPRING BUSHING KIT	50054	VIBRATION MOUNT
32042	MOTOR MOUNT	33504	TORQUE ROD BUSHING	34540	CAB MOUNT BUSHING KIT	50064	TRAILER & DOCK BUMPER

Thank you for your continued support of STEMCO.